



RT700i/RT730i BARCODE PRINTER USER MANUAL



CONTENTS

| | | |
|----------|--|------------|
| 1 | Barcode Printer | 001 |
| 1.1 | Box Content | 001 |
| 1.2 | Getting to Know Your Printer | 002 |
| 2 | Printer Setup | 006 |
| 2.1 | Open the Printer | 006 |
| 2.2 | Loading the Ribbon | 007 |
| 2.3 | Loading the Label Roll Module | 012 |
| 2.4 | Connecting the Printer to the Host Computer | 014 |
| 2.5 | Installing Printer Driver and GoLabel with Super Wizard CD | 016 |
| 3 | Printer Setting and Control | 021 |
| 3.1 | Operation Panel | 021 |
| 3.2 | LCD Interface Introduction | 022 |
| 3.3 | LCD Interface Function | 027 |
| 3.4 | Label Calibration and Self Test | 031 |
| 3.5 | Error Alerts | 033 |
| 4 | NetSetting for Ethernet | 035 |
| 4.1 | Installing the NetSetting Software | 035 |
| 4.2 | The Interface of NetSetting | 036 |
| 5 | Accessories | 043 |
| 5.1 | Preparation Steps | 043 |
| 5.2 | Installing the Label Dispenser | 045 |
| 5.3 | Installing the Cutter | 051 |
| 6 | Maintenance and Adjustment | 055 |
| 6.1 | Cleaning the Print Head | 055 |
| 6.2 | Troubleshooting | 056 |
| | Appendix | |
| | Product Specifications | |
| | Interface | |

FCC COMPLIANCE STATEMENT FOR AMERICAN USERS

This equipment has been tested and found to comply with the limits for a CLASS A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at own expense.

EMS AND EMI COMPLIANCE STATEMENT FOR EUROPEAN USERS

This equipment has been tested and passed with the requirements relating to electromagnetic compatibility based on the standards EN 55022:1998+A1:2000+A2:2003, CISPR 22, Class A EN 55024: 1998+A1: 2001+A2: 2003, IEC 61000-4 Series EN 61000-3-2/2000&EN 61000-3-3/1995. The equipment also tested and passed in accordance with the European Standard EN55022 for the both Radiated and Conducted emissions limits.

RT700i SERIES TO WHICH THIS DECLARATION RELATES IS IN CONFORMITY WITH THE FOLLOWING STANDARDS

EN55022: 1998, CISPR 22, Class A/EN55024: 1998/IEC 61000-4 Serial/EN61000-3-2: 2000/EN 6100-3-3: 1995/CFR 47, Part 15/CISPR 22 3rd Edition: 1997, Class A/ANSI C63.4: 2001/CNS 13438/IEC60950-1: 2005 (EN 60950-1: 2006+A11: 2009)/ GB4943: 2001/ GB9254: 1998/GB17625.1: 2003/EN60950-1: 2001

Caution

- * Danger of explosion if battery is incorrectly replaced. Replace only with the equivalent type recommended by the manufacturer.
- ** Dispose of used batteries according to the manufacturer's instructions.
- *** Only use with designated power supply adapter model.
- **** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

SAFETY INSTRUCTIONS

Please read the following instructions carefully.


1. Keep the equipment away from humidity.
2. Before you connect the equipment to the power outlet, please check the voltage of the power source.
3. Make sure the printer is off before plugging the power connector into the power jack.
4. It is recommended that you connect the printer to a surge protector to prevent possible transient overvoltage damage.
5. Be careful not to get liquid on the equipment to avoid electrical shock.
6. For safety and warranty reasons, ONLY qualified service personnel should open the equipment.
7. Do not repair or adjust energized equipment under any circumstances.

1 Barcode Printer


1.1 Box Content

Please check that all of the following items are included with your printer.


- RT700i/RT730i Barcode Printer




- Label Stock




- Ribbon Module
Empty Ribbon Core




Ribbon




Ribbon Hubs
Set of 2.




- USB Cable



- Power Adapter
Power Cord



AC Adapter



- RT700i/RT730i Quick Guide



- CD
Including GoLabel software
and RT700i/RT730i user manual.




1 Barcode Printer


1.2 Getting to Know Your Printer

Device Overview

- Front View




- Rear View



1 Barcode Printer


- Bottom View



COVER OF THE MODULE CONNECTION JACKS


Notice

- * Cut-outs are not intended for wall-mount use.




1 Barcode Printer

The Internal View of Printer




1 Barcode Printer

The Printing Mechanism



RIBBON REWIND MECHANISM




COVER

The cover for Ribbon rewind mechanism


NOTCH OF RIBBON REWIND WHEEL

RIBBON REWIND WHEEL

PRINT HEAD



RIBBON SUPPLY MECHANISM



PAPER PRESS BAR

NOTCH OF RIBBON SUPPLY WHEEL


RIBBON SUPPLY WHEEL

2 Printer Setup

2.1 Open the Printer

Open the Printer Cover and the Printing Mechanism

Place the printer on a flat surface. Open the printer cover by pulling the cover release catches on both sides of the printer and lift the printer cover.




2 Printer Setup

2.2 Loading the Ribbon


A New Ribbon Module Installation



1. Attach the ribbon to the empty ribbon core with the adhesive strip at the end of the ribbon.




2. Insert the ribbon hub into empty ribbon core and new ribbon. Wind the ribbon around the empty ribbon core for 2 to 3 circles.




3. A ribbon module is assembled as below.

A NEW RIBBON MODULE




2 Printer Setup

Load the Ribbon on the Printer For Ribbon Supply Module




1. Place the ribbon supply module into the printing mechanism. Please the left-hand side of ribbon hub first. Make sure the holder of ribbon hub is inserted into the notch. Then place the right-hand side of ribbon hub.




2 Printer Setup

2. Unlock the release catch to close the printer cover. Push the release catch forward to unlock it. The ribbon supply module loading is completed.




Load the Ribbon on the Printer For Ribbon Rewind Module




2 Printer Setup

1. Open the cover of ribbon rewind mechanism.




2. Place the ribbon rewind module into the ribbon rewind mechanism.
Please the left-hand side of ribbon hub first. Make sure the holder of ribbon hub is inserted into the notch. Then place the right-hand side of ribbon hub.




2 Printer Setup

3. Turn the ribbon rewind wheel to tighten the ribbon until it has no wrinkles.




4. Close the cover of ribbon rewind mechanism.
The ribbon loading is completed once the ribbon supply module and ribbon rewind module are assembled correctly.




2 Printer Setup

2.3 Loading the Label Roll Module


Loading the Label Stock on the Printer



1. Unlock the ribbon catch and pull to open the label guide plate.




2. Place the label stock on label supply hubs. Make sure the label stock is aligned to both hubs. Adjust the label guide plates to fix the label width. Remember to push the release catch when moving the label guide plates.




2 Printer Setup


3. Feed the Label through the label guides. The label guides will help to prevent the label swaying.



4. Unlock the release catch to close the printer cover.




5. Press the FEED key and make sure the label is fed smoothly. The label loading is completed now.




2 Printer Setup

2.4 Connecting the Printer to the Host Computer

1. Please make sure that the printer is switched off.
2. Connect the power cord to the AC adapter.




Connect the jack of the power adapter to the printer and connect the plug of the power adapter to the socket of the wall.




2 Printer Setup

3. Connect the USB/serial cable to the printer and host computer.




4. Pressing the power button. The power LED indicator should now lights up.



2 Printer Setup

2.5 Installing Printer Driver and GoLabel with Super Wizard CD

1. Insert the Super Wizard CD in the CD/DVD drive of the host computer and the program should pop up automatically. You will see the Welcome screen first. On the Welcome screen, choose "Standard Installation".



2. The wizard will then ask you to make sure your USB and power cables are connected and that the power is turned on. Make sure that is done and then click "Next".



3. The next screen you will see is, "Install the GoLabel Software and Windows driver". Click "Next" to continue.



Notice

- * If the Super Wizard program did not run automatically, you can either turn on the "Auto-run" setting for your CD/DVD driver or double-click the icon of CD/DVD driver to run the program.

2 Printer Setup

4. As the printer driver and GoLabel are installing, a screen will display a progress bar.



5. Once the installation is complete, you can start to make and print labels with GoLabel or through the printer driver.



6. As the optional steps, you can also print a test label or register your printer during the "Standard Installation" procedure.




Notice

- * If you need more resources, tools or reference documents, you can also find them on Super Wizard CD. Just click "Other Choices" on Welcome Screen to access the files.

2 Printer Setup

Installing Printer Driver Directly from CD Folder

1. Insert the product CD in the CD/DVD drive of the host computer and open the "Seagull Drivers" folder on the CD. Select the icon for the driver file and click it to start the installation.



2. Follow the instructions on the screen. The Driver Wizard guides you through the installation procedure. Select "Install printer drivers".




3. Specify your printer model.




2 Printer Setup

- Specify the port used to connect the printer to the host computer.



- Enter a printer name and assign the appropriate rights.




- Once the installation is complete, a summary of the printer settings is displayed. Check whether the printer settings are correct and click "Finish" to start copying the driver files. Wait until copying is complete, then finish the installation.



2 Printer Setup


7. Once the driver installation is complete, the new printer should appear in the "Printers and Faxes" folder.



3 Printer Setting and Control

3.1 Operation Panel

Operation Panel Introduction



POWER Button

Press the POWER button to turn on the printer, and the START UP SCREEN appears. The printer is on "ready to print" status, the LCD screen should display the message "READY" on the screen.

When printer is turned on, keep pressing the POWER button for 3 second will turn the printer off.

FEED Button

When you press the FEED button, the printer moves the label to the defined stop position.

If you are using continuous labels, pressing the FEED button will move label stock until you release the button again.

If you are using individual labels, pressing the FEED button will move only one label.

If the label does not stop at the correct position, you need to run the auto-detection function on the label stock, please see Section 3.4 Label Calibration and Self Test.

3 Setting and Control for Operation Panel

3.2 LCD Interface Introduction

Getting Started



Press the POWER button to turn on the printer, and the START UP SCREEN appears.



If the printer is on "ready to print" status, the LCD screen should display the message "Ready" on the screen.



Please keep pressing ▶ button and wait for the timer to be filled, then the LCD interface will enter into the MAIN PAGE for SETTING MODE. You can make various setting functions in SETTING MODE.





3 Setting and Control for Operation Panel

Operations on Setting Page



On MAIN PAGE, press ▶ or ◀ button to move the cursor and select the functions.

Select a designated function and press FEED button, you will enter the SETTING PAGES for the function.




On SETTING PAGES, press ▶ or ◀ button to select the setting items.

Select a designated function and press FEED button, you will enter the SETTING VALUE PAGES for the function.




3 Setting and Control for Operation Panel

On SETTING VALUE PAGES, press ▲ or ▼ button to change the setting values.



Press FEED button will apply the setting value you just selected, and the red tick will appear to mark the value.



Notice

* The blue arrow indicates the value you are selected.




** The red tick indicates that the selected value is applied now.




3 Setting and Control for Operation Panel

Exit from Current Page to Ready Status


The icon on top-left corner displays the capture of upper level screen and also guides you back to upper level with left or up arrow.



On SETTING VALUE PAGES, press ◀ button will go back to the upper level screen.






On SETTING PAGES, press ▲ button will go back to the MAIN PAGE screen.



3 Setting and Control for Operation Panel

On MAIN PAGE, select the "EXIT" icon and press the FEED button to exit from SETTING MODE and the printer goes back to READY status.



3 Setting and Control for Operation Panel

3.3 LCD Interface Function

Main Page




Printer Setting

Setting items for printer, ex. Printing speed, darkness.
Also includes a Printing Wizard for your ease of printing.


Label Setting

Setting items for printing label, ex. Rotation, Printing position offset.


Device

Option modules and connection port settings.


Analysis

Self-Diagnose functions for printer, ex. TPH testing, self-test page printing.


Exit

Exit from Setting Mode.

3 Setting and Control for Operation Panel

Setting Items in Setting Mode



| | | | |
|--------------|-------------------|------------------------------------|---|
| LCD Language | | English | |
| | | German | |
| | | 繁體中文 | |
| | | 简体中文 | |
| | Speed | 2-5 or 7 | |
| | Darkness | 0-19 | |
| | Wizard | Media Type | Label with Gaps Label with Marks Continuous |
| | | Printer Mode | Direct Thermal Thermat Transfer |
| | | Tear-off Position | 0-40 |
| | | Darkness | 0-19 |
| Sensor | Speed | 2-5 or 7 | |
| | Media Detection | Auto Select | |
| | | See-Through | |
| | | Reflective | |
| | Media Type | Label with Gaps | |
| | | Label with Marks | |
| | | Continuous | |
| | Printing Mode | Direct Thermal Thermat Transfer | |
| | Tear-off Position | 0-40 | |
| | Setting | Top of Form | Apply Cancel |
| | | 850 | |
| | | 852 | |
| | | 437 | |
| | | 860 | |
| | | 863 | |
| | | 865 | |
| | | 857 | |
| | | 861 | |
| | | 862 | |
| Codepage | | | 855 |
| | | | 866 |
| | | | 737 |
| | | | 851 |
| | | | 869 |
| | | | Win 1252 |
| | | | Win 1250 |
| | | Win 1251 | |
| | | Win 1253 | |
| | | Win 1254 | |
| | Win 1255 | | |
| | Win 1257 | | |



| | | |
|-------------------|--|---------------|
| Rotation | | 0° |
| | | 90° |
| | | 180° |
| | | 270° |
| Horizontal Offset | | -100 - 100 |
| Vertical Offset | | -100 - 100 |
| Start Offset | | -100 - 100 |
| Recall Label | | 001 Form Name |
| | | 002 Form Name |

3 Setting and Control for Operation Panel



Device

| | | |
|---------------------|---------------|-----------------|
| Buzzer | | Apply |
| | | Cancel |
| Optional Setting | Option | None |
| | | Cutter |
| | | Label Dispensor |
| | | Applicator |
| | Pre-Printing | Apply |
| | | Cancel |
| Serial Port Setting | Baud Rate | 4800 bps |
| | | 9600 bps |
| | | 19200 bps |
| | | 38400 bps |
| | | 57600 bps |
| | 115200 bps | |
| | Parity | Non |
| | | Odd |
| | | Even |
| | Data bits | 7 bits |
| | | 8 bits |
| | Stop bits | 1 bits |
| | | 2 bits |
| RTC Setting | Clock Display | Apply |
| | | Cancel |
| | RTC Setting | YYYY/MM/DD |
| | | HH:MM:SS |



Analysis

| | | |
|------------------|-----------------|--------|
| Calibration | | Apply |
| | | Cancel |
| Self-test | | Apply |
| | | Cancel |
| TPH Testing | | Apply |
| | | Cancel |
| Reset to Default | | Apply |
| | | Cancel |
| Clear Memory | Label Format | Apply |
| | | Cancel |
| | Graphic | Apply |
| | | Cancel |
| | Bitmap Fonts | Apply |
| | | Cancel |
| | True Type Fonts | Apply |
| | | Cancel |
| | Asian Fonts | Apply |
| | | Cancel |
| | ALL | Apply |
| | | Cancel |



Exit

| |
|------|
| Exit |
|------|

3 Setting and Control for Operation Panel

Status of LCD Interface

When printer is on standby status (ready to print), the LCD interface will display "Ready" on screen. You can only print on this "Ready" status.



If there is any printers error, the LCD screen will display the error screen to show the type of error. You can fix the error according to the notice.



Icon Definition

| | | |
|---|------------------|--|
|  | To upper level | Appears on the NAVIGATION ICON of Setting Pages. It guides you back to upper level by pressing "LEFT" key. |
|  | To upper level | Appears on the NAVIGATION ICON of Setting Value Pages. It guides you back to upper level by pressing "UP" key. |
|  | Lock | On Setting Value pages, press "RIGHT" key to lock the value for preventing unexpected change. |
|  | Unlock | For locked value, press "RIGHT" key again to unlock the value. |
|  | Scroll the value | On Setting Value pages, press "UP" or "DOWN" key to scroll the values for your selection. |

3 Printer Setting and Control

3.4 Label Calibration and Self Test

Label Calibration

The printer can automatically detect and store label height. That means the host computer does not need to transmit the label height to the printer.

Self Test

Self-test function lets you check whether the printer is functioning normally. Here is how you run the label size calibration and self test.

1. Check that the label stock is loaded correctly.
2. Turn off the printer.
3. Turn the printer on again, keeping the FEED button pressed. When the LED starts to flash red, release the FEED button. The printer will now measure the label stock and store the label height.
4. Once the printer has successfully measured the label stock, it will print a self-test label.


The contents of a self-test printout are listed below.

| | |
|---|---------------------------------------|
| Model & Version | RT700i:GX.XXX |
| USB ID setting | USB S/N:12345678 |
| Serial port setting | Serial port:96,N,8,1 |
| MAC address of Ethernet port | MAC Addr:xx-xx-xx-xx-xx-xx |
| IP protocol setting | DHCP Enable |
| IP address of Ethernet port | IP xxx.xxx.xxx.xxx |
| Gateway setting | Gateway xxx.xxx.xxx.xxx |
| Netmask setting | Sub-Mask xxx.xxx.xxx.xxx |
| | ##### |
| Number of DRAM installed | 1 DRAM installed |
| Image buffer size | Image buffer size:1500 KB |
| Number of forms | 0000 FORM(S) IN MEMORY |
| Number of graphics | 0000 GRAPHIC(S) IN MEMORY |
| Number of fonts | 000 FONT(S) IN MEMORY |
| Number of Asian fonts | 000 ASIAN FONT(S) IN MEMORY |
| Number of Databases | 000 DATABASE(S) IN MEMORY |
| Number of Scalable fonts | 000 TTF(S) IN MEMORY |
| Free memory size | 4073 KB FREE MEMORY |
| Speed, Density, Ref. Point, Print direction | ^S4 ^H8 ^R000 ~R200 |
| Label width, Form length, Stop position | ^W102 ^Q100,3 ^E18 |
| Cutter, Label Dispenser, Mode | Option:^D0 ^O0 ^AD |
| Sensor Setting | Reflective AD:1.96 2.84 2.49[0.88_23] |
| Code Page | Code Page:850 |
| Printer is on factory default | Default state=Yes |


3 Printer Setting and Control

Label Calibration Button

Keep pressing calibration button for 1 second, the printer can immediately run the label size calibration.




Calibration button can be used to find correct printing position or eliminate the "Media Error" problem.




3 Setting and Control for Operation Panel


3.5 Error Alerts

In the event of a problem that prevents normal functioning of the printer, you will see an error message on LCD screen and hear some beep signals. Please refer to below table for the error alerts.



| Operation Panel Status | | Type | Beeps | Description | Solution |
|--|---|------------------|---|--|--|
|   <p>TPH opened</p> | Print Head Error | 2 x 4 beeps | The printing mechanism is not correctly closed. | Open the print mechanism and close it again. | |
| |   <p>TPH overheat</p> | Print Head Error | None | High temperature at the print head. | Once the print head has cooled down, the printer switches to standby mode. |
|   <p>Check ribbon setting</p> | Media Error | 2 x 3 beeps | No ribbon is installed and the printer displays an error. | Make sure that the printer is set to direct thermal printing mode. | |
| |   <p>Check paper setting</p> | Media Error | 2 x 2 beeps | The ribbon is finished or the label supply hub is not moving. | Replace the ribbon roll. |
| | | | No paper is detected. | Make sure that the label sensor is positioned correctly. If the sensor still does not detect the paper, run the auto-detection function again. | |
| | | | Paper is finished. | Replace the label roll. | |
| | | | Printer feed problem. | Possible reasons: the print medium has become trapped around the rubber roll; the sensor cannot detect a gap or black mark between the labels; there is no paper. Please reset the sensor. | |

3 Setting and Control for Operation Panel


| Operation Panel | | Status | | |
|---|------------|-------------|--|---|
| | Type | Beeps | Description | Solution |
|  <p>GoDEX FW ver. : G4.000</p> <p>Memory full</p> | | | The memory is full. The printer prints the message "File System full". | Delete unnecessary data or install additional memory. |
|  <p>GoDEX FW ver. : G4.000</p> <p>File name can't be found</p> | File Error | 2 x 2 beeps | Unable to find file. The printer prints the message "File Name not found". | Use the "~X4" command to print all files. Then check whether the files exist and whether the names are correct. |
|  <p>GoDEX FW ver. : G4.000</p> <p>File name duplicated</p> | | | A file of the same name already exists. The printer prints the message "Duplicate Name". | Change the name of the file and try storing it again. |

4 NetSetting for Ethernet


4.1 Installing the NetSetting software

The NetSetting software is used to manage the network configurations when connecting the printer via Ethernet port. It is available on product CD or can be downloaded from official website. To install the NetSetting, please follow below steps.


1. Insert the product CD in the CD/DVD drive of the host computer and open the "Ethernet" folder on the CD.
2. Select the icon for the NetSetting installation file and click it to start the installation.



3. Follow the instructions on the screen. The Setup Wizard guides you through the installation procedure.
4. Specify the "Installation Folder".




5. Click "Next" to start the installation.
6. Once the installation is completed; you will see the NetSetting icon on your desktop.




4 NetSetting for Ethernet

4.2 The Interface of NetSetting

Click the NetSetting icon to start the program; you will see the start page as below. The start page will display the basic information of connected printer and your PC.



Click the magnifier icon to search the Godex printers which are connected via Ethernet port in your network environment. Once a connected Godex printer is detected, it will be listed on the start page.



There are six tabs on the top of interface which can configure different types of network settings. But for the data security reason, you need correct password to enter the configuration pages.

Notice

* The default password is "1111", you can change the password later from the "IP Setting" tab.

4 NetSetting for Ethernet

IP Setting

The IP Setting tab can change the printer name, Port number, Gateway setting and the password for configuring the printer. You can also set the printer's IP address either by DHCP or by Static IP.

The screenshot shows the 'NetSetting IP Setting' window. The title bar includes the NetSetting logo and a 'Language' dropdown. The navigation bar contains icons for printer, IP Network, Home, Mail, Settings, and Refresh. The main content area has the following fields and options:

- Printer Name: Length(1~16)
- Port No:
- Default Gateway:
- Password: Length(1~4)
- Get IP From DHCP Server
- Static IP
- IP Address:
- Subnet Mask:
- Buttons:

You can press "Set" button to apply the settings and "ReGet" button to refresh the setting values.

Notice

* To fully benefit from the NetSetting software, you should be familiar with basic networking principles. Please contact your network administrator for related network setting information.

4 NetSetting for Ethernet

Alert Path Setting

NetSetting will send the alert messages to designated mail account when the error happened on printer. The alert messages are sent by SMTP (Simple Mail Transfer Protocol) or SNMP (Simple Network Management Protocol). You can set or change the configurations of SMTP and SNMP on this "Alert Path Setting" tab.

NetSetting
Alert Path Setting

Language

Printer IP Network Alert Settings Help Refresh

SMTP Notification Enable

Login Account: Length(1~64)
Login Password: Length(1~16)
Server IP Address: xxx.xxx.xxx.xxx
Mail Subject: Length(1~60)
Mail From Address: Length(1~32)
Mail To Address: Length(1~32)
Duration Cycle: 0 ~ 168 Hours
Event Counter: 1 ~ 100

SNMP Notification Enable

SNMP Community: Length(1~16)
SNMP Trap Community: Length(1~16)
Trap IP Address: xxx.xxx.xxx.xxx


Set ReGet

You can press "Set" button to apply the settings and "ReGet" button to refresh the setting values.

4 NetSetting for Ethernet

Alert Message Setting

For the alert message notification function, you can decide which error cases need to be sent out to the operator. Moreover, the alert messages can be set to be sent by SMTP, SNMP or both.



You can press "Set" button to apply the settings and "ReGet" button to refresh the setting values.

4 NetSetting for Ethernet

Printer Configuration

Set or change the configurations of connected printer. Most of key settings for the printer operation can be done by this setting page.

The screenshot shows the 'Printer Configuration' window in the NetSetting application. The window title is 'Printer Configuration' and it has a 'Language' dropdown menu in the top right corner. Below the title bar is a navigation bar with several icons: a printer, IP NETWORK, a red circle with a white exclamation mark, a gear, a green 'OK' button, and a refresh icon. The main content area is titled 'Printer Setup' and contains several settings:

| Printer Model | Resolution | Speed | Darkness | Stripper/Applicator | Labels per Cut | Printing Mode |
|---------------|------------|-------|----------|---------------------|----------------|----------------|
| RT700i | 203 | 4 | 10 | 0 (None) | 0 | Thermal Transf |

Below the 'Printer Setup' section are two sub-sections:

- PC Com Port Settings:**
 - Baud Rate: 9600
 - Parity: None
 - Data Bits: 8
 - Stop Bits: 1
- Miscellaneous:**
 - LCD Language: (empty)
 - Keyboard Language: (empty)
 - Code Page: Code Page 850
 - Buzzer: ON
 - Sensing Mode: 2 - Automatic
 - Smart Backfeed: OFF
 - Top Of Form: ON

At the bottom of the window are two buttons: 'Set' and 'ReGet'.


You can press "Set" button to apply the settings and "ReGet" button to refresh the setting values.

4 NetSetting for Ethernet

User Command

The "User Command" tab provides a communication interface for operator to control the printer. Input printer commands in "Input Command" window and press "Send Command" button, the commands will be sent to the printer.

For some commands that will return response message, the message will be displayed in "Output Message" window.




You can press "Send Command" button to send printer commands via Ethernet port and control the printer remotely.

4 NetSetting for Ethernet

Firmware Download

On "Firmware Download" tab, the current version of printer firmware will be showed on the screen. If you need to update the printer firmware, just specify the file location of firmware file and press "Start Download Firmware" button. The printer firmware then can be updated remotely.




In addition to the firmware update, you can press "Recover To Factory Settings" button to restore the printer configurations back to factory default.

5 Accessories

5.1 Preparation Steps


Before installing the optional modules, please make some preparations as follows.

1. Turn off the printer :
Remember to switch off the printer before installing any module.
2. Open the printer cover and the printing mechanism :
Open the printer cover by pulling the release catches on both sides of the printer and lift the cover.
Please see the Section 2.1 for further information about Open the Printer.



The printing mechanism is lifted up with the printer cover

3. Remove the front cover :
Please pull upward to remove the front cover.





FRONT COVER

5 Accessories

4. Remove the platen :

Lift up the release clips on both sides of the platen to release and pull upward the platen.



5. Ribbon loading :

Please see the Section 2.2 for further information about Loading the Ribbon.


6. Label loading

Please see the Section 2.3 for further information about Loading the Label Roll Module.

5 Accessories

5.2 Installing the Label Dispenser

The Overview of the Label Dispenser




Preparation Steps

Please see the Section 5.1 Preparation Steps to complete the preparation steps before installing the label dispenser.

Installing the Label Dispenser

1. Pass the connection cable through the slot of the printer.




Notice


- * A label liner thickness of $0.006 \text{ mm} \pm 10\%$ and a weight of $65 \text{ g/m}^2 \pm 6\%$ are recommended.
- ** The label dispenser will take labels up to a max. width of 118 mm.
- *** When using the label dispenser, set the stop position (printer command ^E) to 13.

5 Accessories


2. Place label dispenser to align both holes of screw and then tighten the screws.



3. Place the platen back to the printer and lock the clips.




4. Close the printer cover and printing mechanism. Then to turn the printer upside down.




5 Accessories


5. Open the cover on the bottom of printer.



6. Plug the connector for the label dispenser to the jack.




7. Close the cover of the module connection jacks.



Notice


- * The printer must be switched off when plugging the connector, or the motherboard may be destroyed!
- ** There are 2 jacks : the lower jack for the label dispenser, the upper jack for the cutter.




5 Accessories

Loading Label Roll with the Label Dispenser Module

1. Remove the first label from the label stock.



2. Feed the Label stock through the label guides.
And pull the label liner through the platen and the steel of the label dispenser.




Notice


* Labels should be at least 25 mm high.

5 Accessories

3. The feeding path of label and liner should be as shown in below graphic.




4. Close the label dispenser and printer cover. The installation is completed now.




5 Accessories

5. Press the FEED button to feed the label. The label will be peeled from the liner while it passes through the label dispenser.



Notice


- * There is a paper sensor on the Label Dispenser module. It will stop the printing if it is covered by label. Remove the last printed label and the printer will then continue to print next label.



5 Accessories

5.3 Installing the Cutter

The Overview of the Cutter




Preparation Steps

Please see the Section 5.1 Preparation Steps to complete the preparation steps before installing the cutter.

Installing the Cutter

1. Pass the connection cable through the slot of the printer.




Notice


- * Remember to switch off the printer before installing the cutter.
- ** Do not use to cut adhesive labels! Glue residue will be left on the cutter blade and impair its functioning. The cutter has a blade life of 400,000 cuts when using paper liner which is 250µm thick and 3 inches wide.
- *** You can cut paper with a max. width of 116mm.
- ****With the cutter installed, set the stop position in Qlabel to 30, and the E value to 30.

5 Accessories


2. Place the cutter to align both holes of screw and then tighten the screws.



3. Place the platen back to the printer and lock the clips.




4. Close the printer cover and printing mechanism. Then to turn the printer upside down.




5 Accessories


5. Open the cover on the bottom of printer.



6. Plug the connector for the cutter to the jack.




7. Close the cover of the module connection jacks.



Notice


- * The printer must be switched off, or the motherboard may be destroyed!
- ** There are 2 jacks : the lower jack for the label dispenser, the upper jack for the cutter.




5 Accessories

Installing the Label Roll Module on the Printer

1. Pass the labels through the guides and the cutter.



2. Close the top cover and printing mechanism. To finish, press the FEED button to set the label position.



Notice

- * We advise against using inside wound label stock.
- ** Labels should be at least 116 mm high. When using the printer with the cutter, you should set the stop position (^E) to 30.

6 Maintenance and Adjustment


6.1 Cleaning the Print Head

Dirt on the print head or ribbon, or glue residue from the label stock may result in inadequate print quality. The printer cover must therefore always be closed during printing. Keeping dirt and dust away from the paper or labels ensures a good print quality and a longer lifespan of the print head.

Cleaning Steps

Here is how you clean the print head.

1. Turn off the printer.
2. Open the printer cover.
3. Remove the ribbon.
4. To remove any label residue or other dirt from the print head (see red arrow), please use a soft lint-free cloth dipped in alcohol.



Notice

- * The print head should be cleaned once a week.
- ** Please make sure that there are no metal fragments or other hard particles on the soft cloth used to clean the print head.

6.2 Troubleshooting

| Problem | Solution |
|---|--|
| The printer is switched on but the LED does not light up. | <ul style="list-style-type: none"> ◆ Check the power supply. Please see the Section 2.4 |
| The LED lights up red and printing is interrupted. | <ul style="list-style-type: none"> ◆ Check the software settings (driver settings) or command codes. ◆ Look for the error alert in the table in Section 3.5. Error Alerts. ◆ Check whether the print mechanism is closed correctly. Please see the Section 3.5 |
| The label stock passes through the printer but no image is printed. | <ul style="list-style-type: none"> ◆ Please make sure that the label stock is loaded the right way up and that it is suitable material. ◆ Choose the correct printer driver. ◆ Choose the correct label stock and a suitable printing mode. |
| The label stock jams during printing. | <ul style="list-style-type: none"> ◆ Clear the paper jam. Remove any label material left on the thermal print head and clean the print head using a soft lint-free cloth dipped in alcohol. Please see the Section 6.1 |
| There is no printed image on some parts of the label. | <ul style="list-style-type: none"> ◆ Check whether any label material or ribbon is stuck to the thermal print head. ◆ Check for errors in the application software. ◆ Check whether the starting position has been set incorrectly. ◆ Check the ribbon for wrinkles. |
| There is no printed image on part of the label or the image is blurred. | <ul style="list-style-type: none"> ◆ Check the thermal print head for dust or other dirt. ◆ Use the internal “~T” command to check whether the thermal print head will carry out a complete print job. ◆ Check the quality of the print medium. |
| The printed image is positioned incorrectly. | <ul style="list-style-type: none"> ◆ Check whether there is paper or dust covering the sensor. ◆ Check whether the label stock is suitable. Contact your supplier. ◆ Check the paper guide settings. |
| A label is missed out during printing. | <ul style="list-style-type: none"> ◆ Check the label height setting. ◆ Check whether there is dust covering the sensor. ◆ Run the auto-detection function. Please see the Section 3.4 |
| The printed image is blurred. | <ul style="list-style-type: none"> ◆ Check the darkness setting. ◆ Check the thermal print head for dust or dirt. Please see the Section 6.1 |
| The cutter does not cut off the labels in a straight line. | <ul style="list-style-type: none"> ◆ Check whether the label stock is positioned straight. |
| The cutter does not cut off the labels completely. | <ul style="list-style-type: none"> ◆ Check whether the label is more than 0.2 mm thick. |
| When using the cutter, the labels are not fed through or cut off incorrectly. | <ul style="list-style-type: none"> ◆ Check whether the cutter has been correctly installed. ◆ Check whether the paper guides are functioning correctly. |
| The label dispenser is not functioning normally. | <ul style="list-style-type: none"> ◆ Check whether there is dust on the label dispenser. ◆ Check whether the label stock is positioned correctly. |

Notice

* If any problems occur that are not described here, please contact your dealer.

APPENDIX

PRODUCT SPECIFICATIONS

| Model | | RT700i | RT730i |
|-------------------------|------------------------------|--|-------------------------------------|
| Print Method | | Thermal Transfer/Direct Thermal | |
| Resolution | | 203dpi(8dots/mm) | 300dpi(12dots/mm) |
| Print Speed | | Up to 7IPS(177mm/s) | 5IPS(127 mm/s) |
| Print Width | | 4.25"(108mm) | 4.16"(105.7mm) |
| Print Length | | Min. 0.16"(4mm)**; Max. 68"(1727mm) | Min. 0.16"(4 mm)**; Max. 30"(762mm) |
| Memory | Flash | 8MB Flash(4MB for user storage) | |
| | SDRAM | 16MB SDRAM | |
| Sensor Type | | Adjustable reflective sensor(full range) Fixed transmissive sensor central aligned | |
| Media | Types | Continuous form, gap labels, black mark sensing, and punched hole; label length set by auto sensing or programming | |
| | Width | 1"(25.4mm)Min.-4.64"(118mm)Max. | |
| | Thickness | 0.003"(0.06mm)Min.-0.01"(0.2mm)Max. | |
| | Label Roll Diameter | Max. 5"(127mm) | |
| | Core Diameter | 1", 1.5"(25.4mm, 38.1mm) | |
| Ribbon | Types | Wax, wax/resin, resin | |
| | Length | 981"(300m) | |
| | Width | 1.18"Min-4.33"(30mm-110mm)Max | |
| | Ribbon Roll Diameter | 2.67"(68mm) | |
| | Core Diameter | 1"(25.4mm) | |
| Printer Language | | EZPL, GEPL, GZPL auto switch | |
| Software | Label Design Software | GoLabel (for EZPL only) | |
| | Driver | Windows 2000, XP, Vista, 7, Windows Server 2003&2008 | |
| | DLL | Windows 2000, XP and Vista | |
| Resident Fonts | Bitmap Fonts | 6, 8, 10, 12, 14, 18, 24, 30, 16X26 and OCR A&B Bitmap fonts 90°, 180°, 270° rotatable, single characters 90°, 180°, 270° rotatable Bitmap fonts 8 times expandable in horizontal and vertical directions | |
| | Scalable Fonts | 90°, 180°, 270° rotatable | |
| Download Fonts | Bitmap Fonts | Bitmap fonts 90°, 180°, 270° rotatable, single characters 90°, 180°, 270° rotatable | |
| | Asian Fonts | Asian fonts 90°, 180°, 270° rotatable and 8 times expandable in horizontal and vertical directions | |
| Barcodes | Scalable Fonts | Scalable fonts 90°, 180°, 270° rotatable | |
| | 1-D Bar codes | Code 39, Code 93, EAN 8/13(add on 2 & 5), UPC A/E(add on 2&5), I 2 of 5&I 2 of 5 with Shipping Bearer Bars, Codabar, Code 128(subset A, B, C), EAN 128, RPS 128, UCC 128, UCC/EAN-128 K-Mart, Random Weight, Post NET, ITF 14, China Postal Code, HIBC, MSI, Plessey, Telepen, FIM and GS1 DataBar | |
| | 2-D Bar codes | PDF417, Datamatrix code, MaxiCode, QR code, Micro PDF417, Micro QR code and Aztec code | |
| Code Pages | | CODEPAGE 437, 850, 851, 852, 855, 857, 860, 861, 862, 863, 865, 866, 869, 737 WINDOWS 1250, 1251, 1252, 1253, 1254, 1255, 1257 Unicode UTF8, UTF16 | |
| Graphics | | Resident graphic file types are BMP and PCX, other graphic formats are downloadable from the software | |
| Interfaces | | USB 2.0 Serial port: RS-232(DB-9) USB Host Ethernet 10/100Mbps print server | |
| Control Panel | | Color TFT LCD with navigation button Calibration button Power on/off button | |

APPENDIX

PRODUCT SPECIFICATIONS

| Model | RT700i | RT730i | |
|-------------------------|---|-------------------------------|--|
| Real Time Clock | Standard | | |
| Power | Auto Switching 100-240VAC, 50-60Hz | | |
| Environment | Operation Temperature | 41°F to 104°F(5°C to 40°C) | |
| | Storage Temperature | -4°F to 122°F (-20°C to 50°C) | |
| Humidity | Operation | 30-85%, non-condensing | |
| | Storage | 10-90%, non-condensing | |
| Agency Approvals | CE(EMC), FCC Class A, CB and CCC, cUL | | |
| Dimension | Length | 11.0" (280mm) | |
| | Height | 7.3" (186mm) | |
| | Width | 8.3" (210mm) | |
| Weight | 6.6 lbs (3.0Kg) ,excluding consumables | | |
| Options | Bluetooth module Guillotine cutter Label dispenser External label roll holder for 10" (250 mm) O.D. label rolls External label rewinder | | |

Notice

- * Specifications are subject to change without notice. All company and/or product names are trademarks and/or registered trademarks of their respective owners.
- ** Minimum print height specification compliance can be dependent on non-standard material variables such as label type, thickness, spacing, liner construction, etc. Godex is pleased to test non-standard materials for minimum height printing capability.

APPENDIX

INTERFACE

Pinout Description

- USB

Connector Type : Type B

| Pin NO. | 1 | 2 | 3 | 4 |
|----------|------|----|----|-----|
| Function | VBUS | D- | D+ | GND |

- Serial Port

Default settings : Baud rate 9600, no parity, 8 data bits, 1 stop bit, XON/XOFF protocol and RTS/CTS

| RS232 Housing(9-pin to 9-pin) | | | |
|-------------------------------|---|----------|----------------|
| DB9 Socket | | DB9 Plug | |
| - | 1 | 1 | +5V, max 500mA |
| RXD | 2 | 2 | TXD |
| TXD | 3 | 3 | RXD |
| DTR | 4 | 4 | N/C |
| GND | 5 | 5 | GND |
| DSR | 6 | 6 | RTS |
| RTS | 7 | 7 | CTS |
| CTS | 8 | 8 | RTS |
| RI | 9 | 9 | N/C |
| Computer | | | Printer |

Notice

- * The total current to the serial port may not exceed 500mA.